

Sand in the water

If the sand is new, all excess sand is washed away with the backwash. Only when there is no more sand coming out of the pump when using the backwash, the sand filter pump can be switched to filter mode. If the sand filter pump is set to filter before this point, the sand will be discharged into the pool.

Using new sand with the 4-way valve:

- Step 1:** Remove all sand from the pool
- Step 2:** Check that the tank has the correct amount of sand and top it up if necessary
- Step 3:** Make sure there is no sand in the central pipe of the tank
- Step 4:** Perform a backwash until the water is clean



You can check this by feeling the water with your hand, as soon as there is no sand left, you can stop.

Using new sand with the 6-way valve:

- Step 1:** Remove all sand from the pool
- Step 2:** Check that the tank has the correct amount of sand and top it up if necessary
- Step 3:** Make sure there is no sand in the central pipe of the tank

Sand in the water

Step 4: Perform a backwash until the water is clean



You can check this by feeling the water with your hand, as soon as there is no sand left, you can stop.

Step 5: Set the system to rinse for at least 1 minute to make sure the filter media is placed correctly again



For more information, visit the INTEX customer support portal
www.intexsupport.com